


Load cell module MCE 2010



Important Information

For SD, SDC, SDM, MD, FD, SOTD, GDS, SDLX and SLCAD load cells, the serial number of load cell and load cell module must be identical.

BNC connector for load cell

Load cell program number

Load cell serial number

*** MUST match the load cell ***