

## **4040C COMMUNICATION MODULE**

**BIN communication in a 4x40C system**

Applies for:

Program no.: BIN\_1LC.090609.1

Document no.: 0609mu4040CE-1

Date: 2009-12-22

Rev.: 1

## 1) CONTENTS

1) CONTENTS.....	2
2) INTRODUCTION .....	3
2.1 Introduction.....	3
3) DATA EXCHANGE .....	4
3.1 BIN Mode (Binary Mode) .....	4
3.1.1 Polled/Continuous operation .....	4
3.1.2 BIN Protocol Format .....	5
3.1.3 Loadcell status codes .....	6
3.2 Filtering.....	7
4) HARDWARE DESCRIPTION .....	8
4.1 4x40C front panel .....	8
4.1.1 Connection of power .....	8
4.1.2 Connection of loadcells .....	8
4.1.3 Connection of external units with J2 connector .....	8
4.1.4 SW1 settings .....	9
4.1.5 Light Emitting Diodes (LEDs) .....	9
4.2 4040C communication module .....	10
4.2.1 SW2 settings .....	10
4.2.2 Jumper settings .....	11
4.2.3 Light Emitting Diodes (LEDs) .....	11
4.2.4 JTAG connector.....	11

## 2) INTRODUCTION

### 2.1 Introduction

This document describes the use of a 4040C communication module from Eilersen Electric, when it is equipped with the program listed on the front page.

With the program specified on the front page, the 4040C communication module is capable of transferring weight data from a connected loadcell on an RS485 channel using a binary protocol.

By use of DIP switches it is possible to select the resolution (0,1 gram or 1 gram) by which the weight is represented.

By use of DIP switches it is possible to configure the averaging period to 2, 10, 50 or 100 ms.

By use of DIP switches it is possible to include one of 15 different FIR filters, that will be used to filter the loadcell signal.

The external device will typically be a PC, that is connected through a RS485 to USB converter.

## 3) DATA EXCHANGE

### 3.1 BIN Mode (Binary Mode)

The 4040C module will communicate with the following specifications:

Specification:	RS485 (2-wire)
Baudrate:	115200 bps
Data bits:	8
Parity:	None
Stop bits:	1
Protocol:	Master-Slave BIN protocol as described below

#### 3.1.1 Polled/Continuous operation

The 4x40C system unit can be set to either Polled or Continuous operation. This is done using Sw2.8 as described later.

In Polled operation the 4040C module operates as described in the next chapter; i.e. it only transmits its weight response telegram when it receives a weight request telegram from its RS485 master.

In Continuous operation the 4040C module automatically transmits its weight response telegram upon completion of every averaging period; i.e. the 4040C module does not need to receive a weight request telegram from its RS485 master.

**Note:** If the 4040C module is placed in Continuous operation the RS485 master should not perform any transmissions in order to avoid conflicts on the RS485 bus.

### 3.1.2 BIN Protocol Format

The 4x40C system unit communicates with the external equipment using a master-slave binary protocol where the 4x40C system unit acts as a slave.

The 4x40C system unit is capable of receiving a weight request telegram with the following format:

**w**

The weight request telegram contains:

**w** is a 'W' character (ASCII 57h).

When the 4x40C system unit receives a weight request telegram, a weight response telegram is transmitted from the 4x40C system unit as an acknowledge. The weight response telegram has the following format:

**<STX> <SS<sub>1</sub>> <WWW<sub>1</sub>> <BCC> <ETX>**

The weight response telegrams contains:

<b>&lt;STX&gt;</b>	STX character (ASCII 02h).
<b>SS<sub>x</sub></b>	Status value for loadcell(x). The value is a 2 byte (one word – 16 bit unsigned integer) binary number with MSB first indicating the status code of loadcell(x).
<b>WWW<sub>x</sub></b>	Weight value for loadcell(x). The value is a 4 byte (one double word – 32 bit signed integer) binary number with MSB first indicating the current weight signal in the selected resolution for loadcell(x). The value is the result of the latest completed averaging.
<b>&lt;BCC&gt;</b>	Checksum.
<b>&lt;ETX&gt;</b>	ETX character (ASCII 03h).

The checksum is calculated by logical XOR of all preceding characters in the telegram including the STX character; i.e. the BCC itself and the ETX character are not included.

### 3.1.3 Loadcell status codes

The following loadcell status codes are possible. If more than one error condition is present the status codes are OR'ed together.

<b>CODE (Hex)</b>	<b>CAUSE</b>
0001	<i>Reserved for future use</i>
0002	<i>Reserved for future use</i>
0004	<i>Reserved for future use</i>
0008	<i>Reserved for future use</i>
0010	<i>Reserved for future use</i>
0020	<i>Reserved for future use</i>
0040	<b>No answer from loadcell</b> Bad connection between loadcell and 4040C?
0080	<i>Reserved for future use</i>
0100	<i>Reserved for future use</i>
0200	<i>Reserved for future use</i>
0400	<i>Reserved for future use</i>
0800	<b>No loadcell answer</b> Bad connection between loadcell and 4040C?
1000	<i>Reserved for future use</i>
2000	<i>Reserved for future use</i>
4000	<i>Reserved for future use</i>
8000	<i>Reserved for future use</i>

### 3.2 Filtering

By use of DIP-switches it is possible to include one of 15 different FIR filters, that will be used to filter the loadcell signals. Thus it is possible, to send the unfiltered loadcell signals achieved over each averaging/sample period (Tavg) through one of the following FIR filters, before the results are transmitted on the RS485 channel:

SW1.1	SW1.2	SW1.3	SW1.4	No.	Taps	Frequency				Damping
						Tavg 2ms	Tavg 10ms	Tavg 50ms	Tavg 100ms	
OFF	OFF	OFF	OFF	0	-	-	-	-	-	-
ON	OFF	OFF	OFF	1	7	120 Hz	24 Hz	4.8 Hz	2.4 Hz	-60dB
OFF	ON	OFF	OFF	2	9	100 Hz	20 Hz	4.0 Hz	2.0 Hz	-60dB
ON	ON	OFF	OFF	3	9	120 Hz	24 Hz	4.8 Hz	2.4 Hz	-80dB
OFF	OFF	ON	OFF	4	12	80 Hz	16 Hz	3.2 Hz	1.6 Hz	-60dB
ON	OFF	ON	OFF	5	12	100 Hz	20 Hz	4.0 Hz	2.0 Hz	-80dB
OFF	ON	ON	OFF	6	15	80 Hz	16 Hz	3.2 Hz	1.6 Hz	-80dB
ON	ON	ON	OFF	7	17	60 Hz	12 Hz	2.4 Hz	1.2 Hz	-60dB
OFF	OFF	OFF	ON	8	21	60 Hz	12 Hz	2.4 Hz	1.2 Hz	-80dB
ON	OFF	OFF	ON	9	25	40 Hz	8 Hz	1.6 Hz	0.8 Hz	-60dB
OFF	ON	OFF	ON	10	32	40 Hz	8 Hz	1.6 Hz	0.8 Hz	-80dB
ON	ON	OFF	ON	11	50	20 Hz	4 Hz	0.8 Hz	0.4 Hz	-60dB
OFF	OFF	ON	ON	12	64	20 Hz	4 Hz	0.8 Hz	0.4 Hz	-80dB
ON	OFF	ON	ON	13	67	15 Hz	3 Hz	0.6 Hz	0.3 Hz	-60dB
OFF	ON	ON	ON	14	85	15 Hz	3 Hz	0.6 Hz	0.3 Hz	-80dB
ON	ON	ON	ON	15	100	10 Hz	2 Hz	0.4 Hz	0.2 Hz	-60dB

**NOTE:** With all four switches OFF, no filtering is performed.

## 4) HARDWARE DESCRIPTION

### 4.1 4x40C front panel

This chapter describes the connections, DIP-switch settings and lamp indications that are available on the 4x40C front panel.

#### 4.1.1 Connection of power

The 4x40C system unit is powered by applying +24VDC on a two pole connector as specified on the front panel of the 4x40C system unit. This powers the 4040C communication module as well as the loadcells.

#### 4.1.2 Connection of loadcells

The loadcells must be connected to the available BNC connectors in the front panel of the 4x40C system unit. The loadcells are connected starting with the connector marked 1 and continuing onwards in rising order. Thus if three loadcells are to be connected, they should be connected to the BNC connectors marked 1, 2 and 3.

#### 4.1.3 Connection of external units with J2 connector

The 4040C module is connected to an external unit with the J2 connector with these connections:

J2 pin.	Function	Connected to
1	B (-)	RS485-B (-) please see below
2	A (+)	RS485-A (+) please see below
3	I/O	Not connected
4	GND	Gnd

Please notice that in some external systems (especially German) the use of A and B is switched. The use of + and – markings are always the same



#### 4.1.4 SW1 settings

The front panel of the 4x40C system unit is equipped with a 4 pole DIP switch block named SW1. Please note that unless stated otherwise, these switches are **ONLY** read during power-on. These switches are mounted on the 4040C communication module.

<b><u>SWITCH</u></b>	<b><u>FUNCTION</u></b>
Sw1.1-Sw1.4	<b>Filtering</b> Used to select the desired filter as described in an earlier chapter. Note that these switches are read during operation.

#### 4.1.5 Light Emitting Diodes (LEDs)

The front panel of the 4x40C system unit is equipped with a number of status lamps (light emitting diodes). The lamps that are mounted on the 4040C communication module have the following functionality:

<b><u>LED</u></b>	<b><u>FUNCTION</u></b>
TxLC (Yellow)	<b>4040 communication with loadcells</b> Lit when communicating with the connected loadcells.
TxBB (Right - Green)	<b>4040 communication</b> Lit when communicating externally.
LC1 (Red)	<b>Status for loadcell #1</b> Lit if the connection to loadcell #1 is broken.
LC2 (Red)	<b>Status for loadcell #2</b> Lit if the connection to loadcell #2 is broken.
LC3 (Red)	<b>Status for loadcell #3</b> Lit if the connection to loadcell #3 is broken.
LC4 (Red)	<b>Status for loadcell #4</b> Lit if the connection to loadcell #4 is broken.

## 4.2 4040C communication module

This chapter describes the connections, DIP-switch settings and status lamps (LEDs) that are available internally on the 4040C communication module.

### 4.2.1 SW2 settings

The 4040C communication module is internally equipped with a 8 pole DIP switch block named SW2. Please note that these switches are **ONLY** read during power-on. This DIP switch block has the following function:

Sw2.1	Sw2.2	Sw2.3	Number of loadcells
OFF	OFF	OFF	1
ON	OFF	OFF	1
OFF	ON	OFF	1
ON	ON	OFF	1
OFF	OFF	ON	1
ON	OFF	ON	1
OFF	ON	ON	1
ON	ON	ON	1

Sw2.4	Sw2.5	Averaging period (Tavg)
OFF	OFF	2 ms
ON	OFF	10 ms
OFF	ON	50 ms
ON	ON	100 ms

Sw2.6	Resolution
OFF	1 gram (i.e. 1 equals 1 gram)
ON	0,1 gram (i.e. 1 equals 0,1 gram)

<u>SWITCH</u>	<u>FUNCTION</u>
Sw2.7	<i>Reserved for future use</i>

<u>SWITCH</u>	<u>FUNCTION</u>
Sw2.8	<b>Polled/Continuous operation</b> OFF: Polled operation (see protocol description) ON: Continuous operation (see protocol description)

### 4.2.2 Jumper settings

The 4040C communication module is internally equipped with 4 jumpers named P2, P3, P4 and P5. In this system these jumpers must be set as follows:

<u>JUMPER</u>	<u>POSITION</u>
P2	OFF (Loadcell connected to 4040C <b>NOT</b> accessible using SEL1)
P3	OFF (Loadcell connected to 4040C <b>NOT</b> accessible using SEL6)
P4	OFF (Loadcell connected to 4040C <b>NOT</b> accessible using SEL1)
P5	OFF (Loadcell connected to 4040C <b>NOT</b> accessible using SEL6)

### 4.2.3 Light Emitting Diodes (LEDs)

The 4040C communication module is internally equipped with a number of status lamps (light emitting diodes). The lamps have the following functionality:

<u>LED</u>	<u>FUNCTION</u>
<i>D11</i> <i>(Red)</i>	<i>Reserved for future use</i>
<i>D12</i> <i>(Red)</i>	<i>Reserved for future use</i>
<i>D13</i> <i>(Yellow)</i>	<i>Reserved for future use</i>
<i>D14</i> <i>(Yellow)</i>	<i>Reserved for future use</i>

### 4.2.4 JTAG connector

The 4040C communication module is internally equipped with a JTAG connector. The connector (J4) is used exclusively by Eilersen Electric A/S for download of software to the Cygnal processor.